


Manual: N83624 Series

High Performance Programmable
Bidirectional DC Power Supply



Version: 23.01.2026

Official partner of NGI: Service and sales
directly through ET System electronic GmbH.

THE WORLD OF POWER

Your Partner for: DC & AC power supplies, bidirectional AC / DC
solutions, conventional & regenerative loads, and battery cell simulators.





Need assistance or have any questions?
We're here to help – contact us.



Call us at:
+49 (0)6205 - 3948-0



Send us an email:
info@et-system.de



We are available from
Mon. to Thurs.: 8 AM to 5 PM
Fri.: 8 AM to 3 PM

See It. Test It. Trust It.
Schedule a free demo Unit and experience the quality yourself.

Didn't find a suitable product?
We're happy to assist you with a personal consultation

ET System electronic GmbH | Hauptstraße 119-121 | 68804 Altlußheim | Germany

Hunan Next Generation Instrumental T&C Tech. Co., Ltd. (NGI for short)

Without the prior permission and written consent of NGI, no content in this manual may be reproduced in any form (including electronic storage and retrieval or translation into a foreign language).

NGI shall not be liable for errors or for incidental or consequential damages in connection with the provision, use or application of this manual and any information contained herein.

The information provided in this manual is subject to change without notice.

Contact Us

If you have any questions about this product, please contact us in the following way.
export@ngi-tech.com

1 PREFACE	1
2 SAFETY INSTRUCTIONS	2
2.1 Safety Symbols	2
2.2 Safety Precautions	2
3 INSPECTION & INSTALLATION	3
3.1 Inspection	3
3.2 Connection to Power Cord	3
3.3 Precaution	4
3.4 Wiring	5
3.4.1 Regular Wiring	5
3.4.2 Optional Wiring	5
3.4.3 BMS Wiring	5
3.5 Remote Mode	6
4 PRODUCT	8
4.1 Introduction	8
4.2 Dimension	9
4.2.1 Regular Dimension	9
4.2.2 Optional Dimension	10
4.3 Optional Accessory Installation(NB108-2)	12
4.4 Front Panel Introduction	14
4.4.1 Button & Knob	14
4.4.2 Function Button	15
4.4.3 Numeric Button	16
4.4.4 Knob	17
4.5 Rear Panel Introduction	17
4.5.1 Regular	17
4.5.2 Optional	18
4.5.3 Channel Interface (Regular)	18
4.5.4 Channel Interface (Optional)	19
4.5.5 RS232 Interface	20
4.5.6 LAN Port	21
4.5.7 CAN Interface	22
4.5.8 Default Communication Parameter	23
5 OPERATION	24
5.1 Interface	25
5.2 Source	26

5.2.2 Operation Example	28
5.3 Charge	29
5.3.1 Parameter Setting	29
5.3.2 Operation Example	30
5.4 SOC Edit	31
5.4.1 Parameter Setting	32
5.4.2 Operation Example	33
5.5 SOC Test	34
5.5.1 Parameter Setting	35
5.5.2 Operation Example	36
5.6 SEQ Edit	37
5.6.1 Parameter Setting	38
5.6.2 Operation Example	40
5.7 SEQ Test	41
5.7.1 Parameter Setting	42
5.7.2 Operation Example	42
5.8 Graph	44
5.9 All View	45
5.10 System	46
5.10.1 Communication Setting	46
5.10.2 Other Parameter	47
5.11 CAN Set	47
5.12 Protection	48
5.13 Fault (Optional)	49
5.14 Factory Reset	50
5.15 About Us	51
6.MAINTENANCE AND SELF-INSPECTION	52
6.1 Regular Maintenance	52
6.2 Fault Self-inspection	52
7 MAIN TECHNICAL DATA	53

Dear Customers

First of all, we greatly appreciate your choice of N83624 series High Performance Multi-channel Battery Simulator (N83624 for short). We are also honored to introduce our company, Hunan Next Generation Instrumental T&C Tech. Co., Ltd.(NGI for short).

About Company

NGI is a professional manufacturer of intelligent equipment and test & control instruments, committed to developing, manufacturing battery simulators, power supplies, electronic loads, and many more instruments. The products can be widely used in the industries of battery, power supply, fuel cell, consumer electronics, new energy vehicle, semiconductor, etc.

NGI maintains close cooperation with many universities and scientific research institutions, and maintains close ties with many industry leaders. We strive to develop high-quality, technology-leading products, provide high-end technologies, and continue to explore new industry measurement and control solutions.

About User Manual

This manual is applied to N83624 series battery simulator, including installation, operation, specifications and other detailed information. Due to the upgrade of instrument, this manual may be revised without notice in future versions.

This manual has been reviewed carefully by NGI for the technical accuracy. The manufacturer declines all responsibility for possible errors in this operation manual, if due to misprints or errors in copying. The manufacturer is not liable for malfunctioning if the product has not correctly been operated.

To ensure the safety and correct use of N83624, please read this manual carefully, especially the safety instructions.

Please keep this manual for future use.

2 Safety Instructions

In the operation and maintenance of the instrument, please strictly comply with the following safety instructions. Any performance regardless of attentions or specific warnings in other chapters of the manual may impair the protective functions provided by the instrument.

NGI shall not be liable for the results caused by the neglect of those instructions.

2.1 Safety Symbols

Please refer to the following table for definitions of international symbols used on the instrument or in the user manual.

Table 1

Symbol	Definition	Symbol	Definition
	DC (direct current)	N	Null line or neutral line
	AC (alternating current)	L	Live line
	AC and DC	I	Power-on
	Three-phase current		Power-off
	Ground		Back-up power
	Protective ground		Power-on state
	Chassis ground		Power-off state
	Signal ground		Risk of electric shock
WARNING	Hazardous sign		High temperature warning
Caution	Be careful		Warning

2.2 Safety Precautions

- **Confirm the AC input voltage before supplying power.**
- **Reliable grounding:** Before operation, the instrument must be reliably grounded to avoid the electric shock.
- **Confirm the fuse:** Ensure to have installed the fuse correctly.
- **Do not open the chassis:** The operator cannot open the instrument chassis. Non-professional operators are not allowed to maintain or adjust it.
- **Do not operate under hazardous conditions:** Do not operate the instrument under flammable or explosive conditions.
- **Confirm the working range:** Make sure the DUT is within N83624's rated range.

3 Inspection & Installation

3.1 Inspection

After receiving N83624, please check the instrument according to the following steps:

1. Check whether the instrument is damaged during transportation. If any severe damage to the package, please contact our authorized distributor or NGL.
2. Check accessories.
3. Check the whole instrument. If N83624 chassis is damaged or has abnormal operation, please contact our authorized distributor or NGL.

3.2 Connection to Power Cord

Before connecting the power cord, observe the following precautions to prevent electric shock and damage to the instrument:



Warnings

- Make sure that the voltage matches the rated voltage of the instrument;
- Make sure the power switch is off;
- Please use the power cord supplied by our company, and connect the power cord to a three-pronged socket with a protective grounding terminal;

Connect one end of the power cord to the input socket on the back panel of the instrument and the other end to the three-pronged socket with a protective grounding terminal.

3.3 Precaution



Warnings

1. Before connecting the power cord, please make sure that the power supply voltage matches the rated power supply voltage of this instrument.
 2. To prevent electric shock and fire, use the power cord supplied by us.
 3. To prevent electric shock, be sure to take protective grounding. Connect the power cord to a three-pronged socket with a protective earth terminal.
-

When the device cannot start normally, please try the following solutions:

1. Check whether the power cord is connected properly, whether the device has been powered normally, and whether the equipment switch is turned on;
2. Check whether the fuse is blown, if the it is, then please replace it with the same specification type fuse to avoid causing accidents.

Table 2

Model	N83624Series
Specification	250V/16A/20×5/Ceramic

The fuse replacement can be performed as follows:

1. Turn off the instrument and remove the power cord.
2. Insert a small screwdriver into the groove at the power socket and gently pry out the fuse holder.
3. Remove the fuse and replace it with one of the specified size.



Warnings

To ensure operator safety, disconnect power to the instrument before replacing the fuse.

3.4 Wiring

3.4.1 Regular Wiring




Figure 1 Regular wiring

3.4.2 Optional Wiring




Figure 2 Optional wiring

3.4.3 BMS Wiring




Figure 3 BMS wiring

3.5 Remote Mode




Figure 4 Remote Control

The N83624 can be connected to a computer via a network cable. Before powering on the computer, make sure that the wires are correctly connected and that the communication settings are correct. The N83624 series battery simulator can also be controlled by multiple units at the same time.

For LAN communication, users need to connect the LAN to the computer through a network cable and a switch. Before powering on the computer, check if the connection is correct and make sure that the IP addresses of all N83624s are not duplicated. N83624 series power supply adopts UDP network communication mode, users can set the IP address, the default port number is 7000 and the default ID is 0. Using RS232 communication mode, baud rate needs to be set. The baud rate can be set to 9600, 19200, 38400, 57600 and 115200.

As is shown in the following figure:




Figure 5 Remote Mode

4 Product

4.1 Introduction

N83624 is a programmable battery simulator with low-power, multi-channel and high-accuracy. Its voltage accuracy is up to 0.6mV, supporting μ A-level current measurement, standalone up to 24 channels. The channels are isolated from each other, which is convenient for series connection. N83624 supports both local operation and remote operation via LAN/RS232/CAN interface. N83624 application software is easy to use, which can meet demands of battery simulators in multi-channel, multiparameter, and complex test environments.

Features

- Voltage range: 0~6V/0~15V
- Current range: 0~1A/0~3A/0~5A
- Voltage accuracy up to 0.6mV
- μ A-level current measurement
- Fast communication response, within 10ms for all channels programming response
- High integration, standalone up to 24 channels, each channel isolated
- Fast dynamic response, voltage rise time less than 20 μ s(For 6V specification)
- Supporting charge mode, battery simulation, SEQ test, SOC test
- 4.3 inch high-definition color LCD screen, local/remote control, standard application software
- LAN port, RS232 interface, CAN interface; dual LAN ports, convenient for cascade application

4.2 Dimension

4.2.1 Regular Dimension

N83624 Series dimension: 132.5mm(H)*482.0mm(W)*559.0mm(D)




Figure 6 Front Panel Dimension(mm)




Figure 7 Side Dimension(mm)




Figure 8 Rear Panel Dimension(mm)

4.2.2 Optional Dimension

N83624+NB108-2 Series Dimension:

132.5mm(H)*482.0mm(W)559.0mm(D)+166.9mm(D)




Figure 9 Front Panel Dimension(mm)




Figure 10 Rear Panel Dimension(mm)




Figure 11 Side Dimension(mm)

4.2.2.1 NB108-2 Dimension




Figure 12 Front Panel Dimension(mm)




Figure 13 Rear Panel Dimension(mm)




Figure 14 Side Dimension(mm)

4.3 Optional Accessory Installation(NB108-2)

The installation method of optional accessory can be carried out according to the following steps.

1. Turn off the AC input power and remove the power cord.
2. Take out the screws, and use a screwdriver to fix the bracket to the holes on the rear panel of N83624.



Figure 15 Bracket Installation

3. Connect NB108-2 power control cable to N83624 power control terminal.
4. Connect NB108-2 channel harness to the channel interface of N83624, taking CH1 as an example.




Figure 16 Wiring Harness Connection

5. Fix NB108-2 to the bracket and the hole bar on rear panel of N83624 with screws.




Figure 17 Fixing NB108-2




Figure 18 Installation Completed



Warnings

To ensure the safety of the operator, please disconnect the input power of the instrument before installing the accessory.

4.4 Front Panel Introduction




Figure 19 Front Panel

Table 3

Number	Name	Function
1	Power switch	Power control
2	Screen	Displaying data
3	Buttons	Operation mode and parameter setting
4	Device model	Displaying model number
5	Air outlet	Exhaust outlet, cooling

4.4.1 Button & Knob

Users can control N83624 via button and knob.




Figure 20 Button & Knob

Number	Name
1	Function buttons
2	Numeric buttons
3	Knob

4.4.2 Function Button




Figure 21 Function Button

Table 5

Button	Function
	To enter Source mode
	To enter all channels readback interface
	Channel switch
	To enter battery simulation /SOC Edit
	To enter SEQ Test /SEQ Edit
	Menu or system setting
	To enter Graph interface
	To lock/unlock
	Compound button, Shift+Battery/SEQ/Menu to enter SOC Edit or SEQ Edit/System

4.4.3 Numeric Button




Figure 22 Numeric Button

Table 6

Button	Function
	Digit input
	To delete
	1. To shift or select the required item in menu 2. To control the cursor scrolling when setting parameter
	To enter the required item, confirm the input, exit from setting or remote operation
	To exit from setting
	To turn on/off the power output for the selected channel

4.4.4 Knob





Figure 23 Knob

Table 7

Knob	Function
	By rotating: to select the required item, adjust the parameter By pressing: to enter the edit interface, confirm the input

4.5 Rear Panel Introduction

4.5.1 Regular




Figure 24 Rear Panel

Table 8

Number	Name	Function
1	Air outlet	Exhaust outlet, cooling
2	Channel interface	Channel output
3	CAN interface	For remote control
4	RS232 interface	For remote control
5	LAN port	For remote control

4.5.2 Optional




Figure 25 Rear Panel

Table 9

Number	Name	Function
1	Air outlet	Exhaust outlet, cooling
2	Channel interface (regular)	Channel output (regular)
3	Fault simulation control terminal	Control power supply and relay
4	CAN interface	For remote control
5	120Ω resistance	Settable resistance, default as off
6	RS232 interface	For remote control
7	LAN port	For remote control
8	AC power socket	AC input power
9	Channel interface (optional)	Channel output (optional)

4.5.3 Channel Interface (Regular)




Figure 26 Channel Interface (Regular)

When the instrument outputs a high current, a voltage drop occurs on the output

output mode to compensate the wire voltage drop.

Table 10 Pin Definition

Symbol	Definition
+	Four-wire system output +
S+	Four-wire system sense +
S-	Four-wire system sense -
-	Four-wire system output -



Notes

The maximum limit of the output/input voltage between the channel interface (+) and (-) is the rated voltage.
The maximum limit of the output/input current between the channel interface (+) and (-) is the rated current.

4.5.4 Channel Interface (Optional)




Figure 27 Channel Interface (Optional)

When the instrument outputs a high current, a voltage drop occurs on the output wire. In order to ensure the measurement accuracy, N83624 adopts the four-wire output mode to compensate the wire voltage drop.

Symbol	Definition
CH1+	Four-wire system output +
S1+	Four-wire system sense +
S1-	Four-wire system sense -
CH1-	Four-wire system output -

! Notes

The maximum limit of the output/input voltage between the channel interface (+) and (-) is the rated voltage.

The maximum limit of the output/input current between the channel interface (+) and (-) is the rated current.

4.5.5 RS232 Interface

On the rear panel, there is a male DB-9 interface with 9 pins.




Figure 28 RS232 Interface

Table 12 RS232 Pin Definition

Pin	Definition
1	NC
2	RXD, receive data
3	TXD, transmit data
4	NC
5	GND, ground
6	NC
7	NC
8	NC
9	NC

4.5.6 LAN Port

There are two LAN ports at N83624 rear panel. Users can choose either LAN port to connect N83624 with computer by an Ethernet cable.

The double LAN design offers feasibility of one computer controlling multiple devices. Below figure shows one computer controlling two devices.




Figure 29 Multiple Devices Connection Diagram

! Notes

N83624 is equipped with three communication interfaces, RS232, LAN and CAN. Users can choose any one to communicate with the computer.

4.5.7 CAN Interface

N83624 is equipped with a CAN bus interface.




Figure 30 RS232 Interface

Table 13 CAN Pin Definition

Pin	Definition
CAN1H	Dominant level
CAN1L	Recessive level
GND	Ground
CAN2H	Dominant level
CAN2L	Recessive level

Users can realize PC communication control through the USB to CAN converter. The connection diagram is shown below.




Figure 31 Connection Diagram

4.5.8 Default Communication Parameter

Table 14

Parameter	N83624 Series Default Value
Default IP Address	192.168.0.123
Default Baud Rate	115200

5 Operation

After the device is switched on, it will enter Source mode directly. Users can enter menu by pressing [**Menu**]. There are fourteen options on the menu: Source, Charge, SOC Test, SOC Edit, SEQ Test, SEQ Edit, All CH, Graph, System, Protection, CAN Set and About Us, Factory Reset.




Figure 32 Menu

This chapter mainly describes the following functions of N83624.

- **Source**
- **Charge**
- **SOC Test**

- SEQ Edit
- SEQ Test
- Graph
- All CH
- Fault (Optional)
- CAN Set
- System
- Protection
- About Us
- Factory Reset

5.1 Interface




Figure 33 Interface Introduction

Number	Instruction
1	Specification
2	Readback area, including voltage, current, power, capacity, temperature. Please press [Shift] first, release the button and then press ◀▶ to switch the parameters.
3	Channel status, including ON/OFF, function mode, OVP/OCP/OPP, etc.
4	Parameter setting area
5	Function mode

5.2 Source

N83624 source mode includes constant voltage and current limit.

Methods to enter **Source** mode:

Method 1: It will directly enter **Source** mode after power-on.

Method 2: Press **[Source]** on the front panel directly.

Method 3: Press **[Menu]**→ Select **[Source]** by pressing ◀▶ or rotating the knob→ Press the knob or **[Enter]**.




Figure 34 Source Mode

Parameter	Description
Channel	To select channel number
CV Value	To set constant voltage value
I-Range	To select current readback range
OUT/I-Limit	To set output current limit

5.2.1 Parameter Setting

■ Channel Selection

Channel selection refers to selecting the present channel to edit parameters or run the present channel.

Methods to select the required channel under **Source** mode:

Method 1: Press **[CH]** directly on the front panel.

Method 2: Press ◀▶ to select **Channel**→ Press **[Enter]** or the knob on **Channel**→ Press ◀▶ to select the required channel→ Press **[Enter]** or the knob to complete selection.

Method 3: Rotate the knob to select **Channel**→ Press **[Enter]** or the knob on **Channel**→ Rotate the knob to select the required channel→ Press **[Enter]** or the knob to complete selection.

Users can select option **ALL** to turn on/off all channels.

■ Current Range

Current range is the current readback range, including three options: high range, low range, and automatic range. When the device is set to automatic range, the readback current range will automatically switch the range according to the actual current value. After switching the range, users need to press ON again to take effect.

Steps to select the required current range under **Source** mode:

1. Press ◀▶ or rotate the knob to select **I-Range**.
2. Press **[Enter]** or the knob on **I-Range**.
3. Press ◀▶ or rotate the knob to select the range required.
4. Press **[Enter]** or the knob to complete selection.

■ CV Value

The settable range is from 0 to rated voltage.

The settable range of OUT/I-Limit is from 0 to rated current. The actual output current will not exceed the setting value.

Methods to set **CV Value** or **OUT/I-Limit** under **Source** mode:

Method 1: Press ◀▶ or rotate the knob to select **CV Value** or **OUT/I-Limit**→Press [Enter] or the knob on **CV Value** or **OUT/I-Limit**→Press numeric buttons to input the value→Press [Enter] or the knob to complete setting.

Method 2: Press ◀▶ or rotate the knob to select **CV Value** or **OUT/I-Limit**→Press [Enter] or the knob on **CV Value** or **OUT/I-Limit**→Press ◀▶ to move the cursor and rotate the knob to adjust the numeric→Press [Enter] or the knob to complete setting.

5.2.2 Operation Example

Step 1: Select the channel to CH1.

Step 2: Set **CV Value** to 6V and press [Enter].

Step 3: Set **I-Range** to Auto and press [Enter].

Step 4: Set **OUT/I-Limit** to 1000mA and press [Enter].

Step 5: Connect a 17kΩ and press [ON/OFF] to enable output.

Step 6: The LCD screen shows the data.




Figure 35 Source Mode

Step 8: After the test completed, press [ON/OFF] to shut off output.

5.3 Charge

Under Charge mode, battery charging and discharging can be simulated.

Steps to enter **Charge** mode:

1. Press [**Menu**] on the front panel.
2. Choose **Charge** by pressing ◀▶ or rotating the knob.
3. Press [**Menu**] or the knob.




Figure 36 Charge Mode

Table 17

Parameter	Description
Channel	To select channel number
CV Value	To set constant voltage value
OUT/I-Limit	To set output current limit
R-Set	To set resistance value

5.3.1 Parameter Setting

■ Channel Selection

Channel selection refers to selecting the present channel to edit parameters or run the present channel.

Methods to select the required channel under **Charge** mode:

Method 1: Press [**CH**] directly on the front panel.

Press ◀▶ to select the required channel→ Press [**Enter**] or the knob to complete selection.

Method 3: Rotate the knob to select **Channel**→ Press [**Enter**] or the knob on **Channel**→ Rotate the knob to select the required channel→ Press [**Enter**] or the knob to complete selection.

Users can select option **ALL** to turn on/off all channels.

■ Output Current Limit

The settable range of OUT/I-Limit is from 0 to rated current. The actual output current will not exceed the setting value.

■ CV Value

The settable range is from 0 to rated voltage.

■ Simulated Resistance

The settable range is from 0mΩ to 99999.9mΩ.

Methods to set **CV Value** or **OUT/I-Limit** or **R-Set** under **Charge** mode:

Method 1: Press ◀▶ or rotate the knob to select **CV Value** or **OUT/I-Limit** or **R-Set**→Press [**Enter**] or the knob on **CV Value** or **OUT/I-Limit** or **R-Set**→Press numeric buttons to input the value→Press [**Enter**] or the knob to complete setting.

Method 2: Press ◀▶ or rotate the knob to select **CV Value** or **OUT/I-Limit** or **R-Set**→Press [**Enter**] or the knob on **CV Value** or **OUT/I-Limit** or **R-Set**→Press ◀▶ to move the cursor and rotate the knob to adjust the numeric→Press [**Enter**] or the knob to complete setting.

5.3.2 Operation Example

Step 1: Select the channel to CH1.

Step 2: Set **CV Value** to 3.6V and press [**Enter**].

Step 3: Set **OUT/I-Limit** to 1000mA and press [**Enter**].

Step 4: Set **R-Set** to 3mΩ and press [**Enter**].

Step 5: Connect a battery and press [**ON/OFF**] to enable output.

Step 6: The LCD screen shows the data.




Figure 37 Charge Mode

Step 7: After the test completed, press [ON/OFF] to shut off output.

5.4 SOC Edit

The SOC function simulates battery charging and discharging. During the battery charging and discharging process, the larger the battery capacity is, the higher the battery open circuit voltage and the lower the battery internal resistance are. On the contrary, when the capacity decreases, the battery open circuit voltage decreases and the internal resistance increases.

Under SOC edit, users can edit multiple steps to form a test program. Up to 8 files can be edited (File 1 ~ File 8). Up to 200 steps can be configured per SOC file. Users can edit the capacity, constant voltage value, input/output current limit and simulated internal resistance of each single step. After editing is completed, users can enter SOC test interface to execute the edited test steps.

Methods to enter **SOC Edit**:

Method 1: Press [Shift] first and then [Battery] on the front panel.

Method 2: Press [Menu]→ Select [SOC Edit] by pressing ◀▶ or rotating the knob→ Press the knob or [Enter].




Figure 38 SOC Edit

Table 18

Parameter	Description
Channel	To select channel number
File No.	To set SOC test file number, range: 1-8
Total Steps	To set the total operation steps. Range: 0-200
Step No.	To set the specific step number. Range:1-200
Q	To set the initial capacity for the corresponding step number
R-Set	To set resistance value,range: 0mΩ-99999.9mΩ
CV Value	To set constant voltage value,range: 0 to rated voltage
OUT/I-Limit	To set output current limit. Loop current should be less than OUT/I-Limit.

5.4.1 Parameter Setting

■ Channel Selection

Channel selection refers to selecting the present channel to edit parameters or run the present channel.

Methods to select the required channel under **SOC Edit** mode:

Method 1: Press **[CH]** directly on the front panel.

Method 2: Press **◀▶** to select **Channel**→ Press **[Enter]** or the knob on **Channel**→ Press **◀▶** to select the required channel→ Press **[Enter]** or the knob to complete selection.

Method 3: Rotate the knob to select **Channel**→ Press **[Enter]** or the knob on

knob to complete selection.

Users can select option **ALL** to turn on/off all channels.

■ File No.

It refers to the work step file executed when the device is running. Settable range is 1-8.

■ Total Steps

It refers to the total steps executed when the device is running. Settable range is 0-200.

■ Step No.

After setting the step number, users can set corresponding parameters. Settable range is 1-200.

■ Capacity

It refers to the capacity for the step under editing.

■ Constant Voltage

Settable range is from 0 to rated voltage.

■ Simulated Resistance

Settable range is from 0mΩ-99999.9mΩ.

■ Output Current Limit

The settable range of OUT/I-Limit is from 0 to rated current. The actual output current will not exceed the setting value.

5.4.2 Operation Example

Step 1: Select the channel to CH1.

Step 2: Set **File No.** to 4 and press [Enter].

Step 3: Set **Total Steps** to 20 and press [Enter].

Parameters for step 1 to step 20 (lead-acid battery discharge model)

Step No.	Capacity (mAh)	Constant Voltage (V)	Output Current Limit (mA)	Resistance (mΩ)
1	10000.00	2.1000	1000.0	10.0
2	9600.00	2.0900	1000.0	11.0
...	...	...	...	...
18	2000.00	1.7700	1000.0	71.0
19	1000.00	1.6900	1000.0	85.0
20	0.00	1.600	1000.0	100.0

After the parameters are all set, the screen will show as below picture.



Figure 39 SOC Edit

Note: To exit from **SOC Edit**, please press [**Menu**] or the function button required.

5.5 SOC Test

After completing SOC Edit, users can enter SOC Test, select the required channel, set the required SOC file number, set initial voltage and turn on the output to run the test steps.

Steps to enter **SOC Test**:

1. Press [**Menu**] on the front panel.
2. Select **SOC Test** by pressing ◀▶ or rotating the knob.
3. Press [**Enter**] or the knob.




Figure 40 SOC Test

Table 20

Parameter	Description
Channel	To select channel number
File No.	To select the required SOC file No.
Initial Volt	To set start voltage
O-C Volt	Displaying the open circuit voltage
Initial Q	Displaying the starting capacity
Present Q	Displaying the present capacity
Present R	Displaying the internal resistance value
Present Step	Displaying the present test step

Note:

The initial voltage should be less than the maximum voltage in the work step and greater than the minimum voltage in the work step.

5.5.1 Parameter Setting

■ Channel Selection

Channel selection refers to selecting the present channel to edit parameters or run the present channel.

Methods to select the required channel under **SOC Test**:

Method 1: Press **[CH]** directly on the front panel.

Method 2: Press **◀▶** to select **Channel**→ Press **[Enter]** or the knob on **Channel**→ Press **◀▶** to select the required channel→ Press **[Enter]** or the knob to complete selection.

Channel→ Rotate the knob to select the required channel→ Press [**Enter**] or the knob to complete selection.

Users can select option **ALL** to turn on/off all channels.

■ **File No.**

Users can select the edited SOC file.

■ **Initial Voltage**

Initial voltage refers to start voltage of simulated battery. After setting, the device will start to charge or discharge at this voltage.

Methods to set **File No.** or **Initial Volt** under **SOC Test**:

Method 1: Press ◀ ▶ or rotate the knob to select **File No.** or **Initial Volt** →Press [**Enter**] or the knob on **File No.** or **Initial Volt** →Press numeric buttons to input the value→Press [**Enter**] or the knob to complete setting.

Method 2: Press ◀ ▶ or rotate the knob to select **File No.** or **Initial Volt**→Press [**Enter**] or the knob on **File No.** or **Initial Volt**→Press ◀ ▶ to move the cursor and rotate the knob to adjust the numeric→Press [**Enter**] or the knob to complete setting.

Note: Initial Volt should be lower than the highest voltage and higher than lowest voltage in the SOC Edit test steps.

5.5.2 Operation Example

Step 1: Select the channel to CH1.

Step 2: Set **File No.** to 4 and press [**Enter**].

Step 3: Set **Initial Volt** to 2.0980V and press [**Enter**].

Step 4: Connect a test object and press [**ON/OFF**] to enable output.

Step 5: The LCD screen shows the data.




Figure 41 SOC Test

Step 6: After the test completed, press [ON/OFF] to shut off output.

5.6 SEQ Edit

Multiple steps can be edited under SEQ Edit. The maximum SEQ files are 10 files with range 1-10. The maximum steps are 200 steps. Constant voltage value, output current limit, input current limit, resistance value and dwell time can be set for each step. Links can also be made between steps. The corresponding cycle times can be set independently.

N83624 judges the number of running steps based on the selected SEQ file. It will run all the steps in sequence, according to the preset output parameters for each step.

Methods to enter **SEQ Edit**:

Method 1: Press [Shift] first and then [SEQ] on the front panel.

Method 2: Press [Menu]→ Select [SEQ Edit] by pressing ◀▶ or rotating the knob→ Press the knob or [Enter].

6V/1A/24CH SEQ Edit

Chanel < CH1 > File No. 1 Total Steps 0

Cycle Times 1 Step No. 1 CV Value 0.0000 V

OUT/I-Limit 0.0 mA R-Set 0.0 mΩ Dwell 0.000 s

Link Start Step -1 Link Stop Step -1 Link Cycle Times 0

Step No.	CV Value (V)	OUT/I-Limit (mA)	R-Set (mΩ)	Dwell (s)

Press [Shift]+[◀] or [▶] to switch the page

Figure 42 SEQ Edit

Table 21

Parameter	Description
Channel	To select channel number
Cycle Times	To set the number of cycles for the file under edit. Range:0-9999
Dwell	To set the dwell time for the step under edit
Link Cycle Times	To set cycle times for the link
File No.	To set the sequence test file number. Range: 1-10
Step No.	To set the step number for editing. Range: 1-200
OUT/I-Limit	To set output current limit. Loop current should be less than OUT/I-Limit.
Link Start Step	To link to the required step after the present step is completed, range -1 to 200. -1 means no link.
Total Steps	To set the total steps of SEQ file. Range: 0-200
CV Value	To set constant voltage value
R-Set	To set resistance value
Link Stop Step	To set the link stop step, range -1 to 200. -1 means no link.

5.6.1 Parameter Setting

■ Channel Selection

Channel selection refers to selecting the present channel to edit parameters or run the present channel.

Methods to select the required channel under **SEQ Edit**:

Method 2: Press ◀▶ to select **Channel**→ Press [Enter] or the knob on **Channel**→ Press ◀▶ to select the required channel→ Press [Enter] or the knob to complete selection.

Method 3: Rotate the knob to select **Channel**→ Press [Enter] or the knob on **Channel**→ Rotate the knob to select the required channel→ Press [Enter] or the knob to complete selection.

Users can select option **ALL** to turn on/off all channels.

■ SEQ File No.

It refers to the work step file executed when the device is running. Settable range is 1-10.

■ Total Steps

It refers to the total steps executed when the device is running. Settable range is 0-200.

■ File Cycle Times

It refers to the cycle times the SEQ file should run. Settable range is 0-9999.

■ Step No.

After setting the step number, users can set corresponding parameters. Settable range is 1-200.

■ Constant Voltage

Settable range is from 0 to rated voltage.

■ Output Current Limit

The settable range of OUT/I-Limit is from 0 to rated current. The actual output current will not exceed the setting value.

■ Simulated Resistance

Settable range is from 0mΩ-99999.9mΩ.

■ Dwell Time

It refers to the running time for the specific time. Settable range is 0-99.999s.

■ Link Start Step No.

same value of Step No., it means Link Start Step is same as Step No.

■ Link Stop Step No.

Settable range is -1-200. -1 means no link. When this parameter is set to zero or the same value of Step No., it means Link Start Step is same as Step No.

Example:

When the step No. is set to 3, setting Link Start Step/Link Stop Step to zero or 3 means still running step number 3.

■ Link Cycle Times

It refers to the cycle times the link step should run.

Example:

For editing Step No. 3, Link Start Step is set to 1, Link Stop Step is set to 2, Link Cycle Times is set to 2. It means after reaching dwell time of step 3, it will run from step 1 to step 2 for twice .

Methods to set the above 12 parameters under **SEQ Edit**:

Method 1: Press ◀▶ or rotate the knob to select the required parameter→Press [Enter] or the knob on the required parameter→Press numeric buttons to input the value→Press [Enter] or the knob to complete setting.

Method 2: Press ◀▶ or rotate the knob to select the required parameter→Press [Enter] or the knob on the required parameter →Press◀▶ to move the cursor and rotate the knob to adjust the numeric→Press [Enter] or the knob to complete setting.

5.6.2 Operation Example

- 1.Choose CH1 under Channel selection.
- 2.Choose file No. and set it to 1,and then enter to confirm.
- 3.Choose total step and set it to 3, and then enter to confirm.
- 4.Choose file operating times and set it to 1, and then enter to confirm.

Step No.	CV value(V)	Output current limitation(mA)	Simulated internal resistance (m Ω)	Running Time(s)
1	2.0000	1000.0	0.1	5.000
2	3.0000	1000.0	0.2	10.000
3	3.5000	1000.0	0.3	20.000

After the parameters are all set, the screen will show as below picture.

The screenshot shows the 'SEQ Edit' interface. At the top, it says '6V/1A/24CH' and 'SEQ Edit'. Below this, there are several parameter fields: 'Chanel' (CH1), 'File No.' (1), 'Total Steps' (3), 'Cycle Times' (1), 'Step No.' (1), 'CV Value' (2.0000 V), 'OUT/I-Limit' (1000.0 mA), 'R-Set' (0.1 m Ω), 'Dwell' (5.000 s), 'Link Start Step' (-1), 'Link Stop Step' (-1), and 'Link Cycle Times' (0). Below these fields is a table with the following data:

Step No.	CV Value (V)	OUT/I-Limit (mA)	R-Set (m Ω)	Dwell (s)
1	2.0000	1000.0	0.1	5.000
2	3.0000	1000.0	0.2	10.000
3	3.5000	1000.0	0.3	20.000

At the bottom, there is a note: 'Press [Shift]+[◀] or [▶] to switch the page'.

Figure 43 SEQ Edit

5.7 SEQ Test

The sequence test mainly determines the step size according to the currently selected running file, and executes sequentially according to the output parameters of each step. The user presses SEQ to enter the "Sequence Test" interface, or selects "Sequence Test" under the "Menu" menu to enter the interface, as shown in Figure 44:




Figure 44 SEQ Test

5.7.1 Parameter Setting

■ Channel Selection

Refer to Chapter 5.2.1

■ File Edit

Select the running file No. currently, Refer to chapter 5.2.1

5.7.2 Operation Example

1. Choose CH1 under Channel selection.

2. Choose file No. and set it to 1, and then enter to confirm.

Please note that this operation should be done after SEQ edit finished.

3. Connect the DUT, press ON/OFF button to enable output.

4. Observe the reading data on the screen.

5. Press ON/OFF button to disable output after test finished.




Figure 45 SEQ Test

5.8 Graph

Users can press Graph or choose Graph from Menu to enter the screen, as shown in Figure 46:




Figure 46 Graph

The graph of any four channels voltage values can be displayed simultaneously.

Operation:

1. Press the [◀] [▶] or rotate the "knob" to move the cursor to the channel display bar.
2. press the "knob" , then rotate the "knob" to switch the channel.
3. press the "knob" to confirm.

After setting the channel, move the cursor to the "Run" and press the "knob" to start.

5.9 All View

Users can press All CH or choose All View from Menu to enter the screen, as shown in Figure 47:




Figure 47 All View

In the All view interface, you can view the voltage value, current value, power value and On/Off status of each channel. Press "Shift "+"◀▶" to switch to other channels.

5.10 System

The System is displayed by pressing Shift+Menu, or by selecting System from the Menu menu. You can set related parameters on the system configuration screen, as shown in Figure 48.



Figure 48 System Setting

5.10.1 Communication Setting

■ IP Address

The default IP address is 192.168.0.123. Users can change the value. After the change is complete, the system restarts to take effect.

To set it up: press the "◀▶" key or rotate the "knob" to move the cursor to the "Network IP" option and press it

Select "Knob" to enter the parameter setting interface. Enter a value using numeric keys and press "Knob" to confirm.

■ Baud Rate

The N83624 supports a variety of baud rates. Users can select 9600, 19200, 38400, 57600, and 115200 as required. The changes take effect after being restarted.

■ Buzzer

This option can set the device key sound ON/OFF.

The N83624 supports Chinese and English display.

■ Network connection

This option can set the network connection to UDP/TCP. After the change is complete, the restart takes effect.

5.10.2 Other Parameter

■ Channel

Please refer to the chapter 5.2.1.

■ Setting Rate

S/Rate: Fast(10ms) /Medi(120ms) /Slow(480ms), Medi defaulted. Please refer to the chapter 5.2.1.

5.11 CAN Set

The user selects CAN Set from the menu to enter the screen, as shown in Figure 49:




Figure 49 CAN Set

Set the CAN ID address of the device (the default value is 1 and the maximum value is 5). When the CAN ID address is 1, the CAN id of the 24 channels are 1-24 in sequence; when the CAN ID address is 2, the CAN ids of the 24 channels are 25-48 in sequence, and so on.

■ CAN Baud Rate

The N83624 supports multiple CAN baud rates. A restart takes effect after the baud rate is changed.

The CAN ID address and CAN baud rate parameters are set in the same way. For details, see Section 5.2.1.

■ Extended CAN ID Address

The extended ID starting address is 1 by default, and the EXT_CAN ID assignment for each channel is similar to the CAN ID address. When this address is used, the device transmits data in extended frames.

■ Upload Time

The device uploads data once at each interval, and the uploaded data contains voltage, current, and power.

5.12 Protection

Users can press the "Menu" button and select "Protection" to enter the interface, the protection parameters can be set in the interface.




Figure 50 Protection

■ Channel

Please refer to the chapter 5.2.1.

■ OVP

If the OVP is triggered, the maximum output voltage will be limited to the protection value, once the OVP is triggered, the output will be shut down immediately and the screen will display the OVP symbol.

■ OCP


If the OCP is triggered, the maximum output/input current will be limited to the protection value, once the OCP is triggered, the output will be shut down immediately and the screen will display the OCP symbol.

■ OPP

If the OPP is triggered, the maximum output power will be limited to the protection value, once the OPP is triggered, the output will be shut down immediately and the screen will display the OPP symbol.

5.13 Fault (Optional)

The N83624 can simulate a variety of battery fault state, including short circuit, negative break, positive break, and opposite polarity. On the Menu menu, choose Fault Simulation to enter the screen, as shown in Figure 51.



■ Channel

Please refer to the chapter 5.2.1.

■ Fault State

Fault status include Short, N_Open, P_Open, Reverse. Please refer to the chapter 5.2.1.

Note: Fault simulation only applies to the source mode, can not be in the charging mode, SOC, SEQ and other modes of fault simulation test; must be set in the operating state of OFF fault simulation and then ON channel.

5.14 Factory Reset

Users press the "Menu" to enter the screen, select "Restore Factory" to enter the interface, press the "Enter" to restore the factory settings, the interface is shown in Figure 52.




Figure 52 Factory Reset

5.15 About Us

Users press "Menu" to enter and select "About Us" to enter the interface, press "Shift", it will show the factory SN number and software version information of N83624.



Figure 53 About Us

6.Maintenance and Self-inspection

6.1 Regular Maintenance

Clean the Device

Please wipe lightly the device with a dry or slightly wet cloth, and do not wipe the inside of it. Make sure the power is disconnected before cleaning.

 **Warning: Disconnect power before cleaning.**

6.2 Fault Self-inspection

Device Fault Self-inspection

Due to system upgrade or hardware problem, the device may break down. Please do the following necessary inspection to eliminate the troubles, which can save your maintenance and time cost. If the troubles cannot be recovered, please contact NGI.

The inspection steps are as below.

- ◆ Check whether the device is powered.
- ◆ Check whether the device can be turned on normally.
- ◆ Check whether the fuse has no damage.
- ◆ Check whether other connectors are correct, including wire cables, plug, etc.
- ◆ Check whether the system configuration is correct.
- ◆ Check whether all the specifications and performances are within the device working range.
- ◆ Check whether the device displays error information.
- ◆ Operate on a replacement device.

Calibration Intervals

It is suggested that N83624 series should be calibrated once a year.

7 Main Technical Data



Measurement accuracy is recognized when the temperature is 18°C~28°C and the relative humidity reaches 80% within one year after calibration. Also, please warm up for half an hour before accuracy measurement.

Table 22

Model	N83624-06-01	N83624-06-03		N83624-06-05			N83624-15-01	
Current	1A/CH	3A/CH		5A/CH			1A/CH	
Voltage	6V/CH	6V/CH		6V/CH			15V/CH	
Power	6W/CH	18W/CH		30W/CH			15W/CH	
Channel	24CH							
CV Mode								
Range	0~6V						0~15V	
Setting Resolution	0.1mV							
Setting Accuracy (23±5°C)	0.6mV						1.5mV	
Readback Resolution	0.1mV							
Readback Accuracy (23±5°C)	0.6mV						1.5mV	
Temperature System(0~40°C)	20ppm/°C							
Long-term Stability	80ppm/1000h							
Voltage Ripple (20Hz~20MHz)	≤2mVrms						≤5mVrms	
CC Mode								
Range	0~1A	0~1mA	0~3A	0~1mA	0~5A	0~1mA	0~1A	0~1mA
Setting Resolution	0.1mA	0.1μA	0.1mA	0.1μA	0.1mA	0.1μA	0.1mA	0.1μA
Setting Accuracy (23±5°C)	1mA	1μA	3mA	1μA	5mA	1μA	1mA	1μA
Readback Resolution	0.1mA	0.1μA	0.1mA	0.1μA	0.1mA	0.1μA	0.1mA	0.1μA
Readback Accuracy (23±5°C)	1mA	1μA	3mA	1μA	5mA	1μA	1mA	1μA
Temperature System(0~40°C)	30ppm/°C							
Long-term Stability	100ppm/1000h							
Dynamic Characteristics								
Voltage Rise Time (no load) (10%-90%F.S. Variation Time)	<20μs						<40μs	

Voltage Rise Time (full load) (10%-90%F.S. Variation Time)	<20μs	<40μs
Voltage Fall Time (no load) (90%-10%F.S. Variation Time)	<3ms	<6ms
Voltage Fall Time (full load) (90%-10%F.S. Variation Time)	<100μs	<200μs
Transient Voltage Drop ¹	200mV	400mV
Transient Recovery Time ²	<100μs	<200μs
Others		
Load Regulation	0.2mV	0.4mV
Remote Compensation Voltage	≤1V	
Output Terminal Contact Resistance (fault simulation optional)	≤20mΩ(5A 6VDC)	
Isolation (Output to Ground)	2000V DC	
Isolation (Channel to Channel)	500V DC	
Earth Leakage Current	<3.5mA @230V AC	<4mA @230V AC
Communication Response Time	≤10ms	
Interface	LAN/RS232/CAN	
AC Input	Single phase, please refer to the voltage mark at the rear panel.	
Temperature	Operating temperature: 0℃~40℃, storage temperature: -20℃~60℃	
Operating Environment	Altitude <2000m, relative humidity: 5%-90%RH(non-condensing), atmospheric pressure: 80-110kPa	
Dimension	Regular: 132.5mm(H)*482.0mm(W)*559.0mm(D) Optional: 132.5mm(H)*482.0mm(W)*559.0mm(D)+ 166.9mm(D)	
Net Weight	Regular: Approx. 17 kg Optional: Approx. 20 kg	

Note 1: Under full voltage output, the load is changed abruptly from 10% to 90%, and the voltage drop value.

Note 2: Under full voltage output, the load is changed abruptly from 10% to 90%, and the voltage is restored to within (original voltage minus 50mV).

This brochure is for reference only, if you need other specifications, please consult NGI for the latest product information. NGI products are constantly updated and technical specifications are subject to change without prior notice.

When multiple N83624s are used in series, the mains power cannot be disconnected when the device channels are ON, all channels must be OFF before disconnecting the mains power, otherwise the device will be damaged!

Cooperation

ET System electronic and NGI

Driving innovation, quality, and service – together

With over 30 years of experience in developing and manufacturing AC/DC power supplies, electronic loads, and battery simulators, ET System is a well-established provider of high-performance power solutions in Germany. Through our strategic partnership with Next Generation Instrumental (NGI) – a leading manufacturer with over 18 years of expertise in DC loads, bidirectional power supplies, and battery cell simulators – we are combining our strengths to offer an even broader and more powerful product portfolio.

This partnership enables:

- Centralized service and technical support in Germany for all NGI cooperation products
- Direct personal contact – from your initial inquiry to after-sales service, via our local team
- Demo equipment stock in Germany – ensuring quick availability for evaluation across Europe
- Local spare parts and selected device inventory – for fast response in service and urgent needs
- Premium quality and reliability from a single source – thanks to seamless integration of NGI products into ET System solutions



Our customers benefit from a unique combination of local engineering expertise, tailored system integration, and a comprehensive product offering – all from one trusted source.

Please note: Our existing product lines will continue to be manufactured in Germany and remain fully available without change.

From initial consultation to system implementation and ongoing support, our headquarters in Altlußheim (Germany) serves as the central competence center for both our own technologies and the entire NGI portfolio throughout Europe.

Need assistance or have any questions?

We're here to help – contact us.



Call us at:

+49 (0)6205 - 3948-0



Send us an email:

info@et-system.de



We are available from

Mon. to Thurs.: 8 AM to 5 PM

Fri.: 8 AM to 3 PM